# **IMIA 1997**

# Stress Corrosion Cracking in Engineering Insurance

### Presented by:

H. Gewalt Gerling
Dr. U. Minkus Gerling
Mr. Wollmann Allianz

### 1 Introduction:

General description / example:

Stress corrosion cracking is defined as the failure of metals under the combined action of a corrosive environment and tensile stresses. The insidious hazard of stress corrosion cracking is its unexpected appearance. For example a component can work for a long time under normal operation conditions and considerably high loads within the acceptable stress range without showing any unusual behaviour. As expected for this passive material there are no signs of uniform or pitting corrosion. Just a slight shift in the surrounding atmosphere though, for example through another application or due to changed operational conditions, can lead to stress corrosion cracking and to rapid failure. With a decreased load this component can resist the same corrosive atmosphere for ever. In other cases normally reliable components, now manufactured by a new process suddenly break - they prove susceptible to stress corrosion cracking due to the fact that the new production process creates residual tensile stresses on the surface (e.g. cold forming, welding). The result is that the combination of external and residual stresses exceed the critical amount for this specific atmosphere.

The initiated crack on the surface propagates continuously through the whole cross-section of the component, depending on the load cycles and the corrosive atmosphere. If the remaining section cannot withstand any longer the steadily increasing stress, a forced fracture will occur. This final fracture usually occurs spontaneously and unexpectedly without any prior evidence or warning. The damage in consequence can be considerable.

Fresh stress corrosion cracks cannot be recognised by visual tests. There are normally no signs of any other form of corrosion (pits or corrosion products - rust). The wide range of non-destructive tests offers various procedures for detecting cracks, but in practice these examinations are only carried out for critical sections of essential components. Many "non essential" components are not or only with prohibitively expensive additional efforts accessible for in depth examinations. As a result and for economical reasons "uncritical" sections are not normally subject to a complete NTD during maintenance overhauls.

There are two other types of failure very closely related to stress corrosion cracking and its mechanism, being the corrosion fatigue and the strain induced corrosion cracking. Especially the boundary between stress corrosion cracking and corrosion fatigue is not clearly defined: there is a large 'grey area'. Due to their importance two separate sections of this paper are devoted to the issues corrosion fatigue and strain induced corrosion cracking.

## 2 Stress corrosion cracking:

### 2.1 Classification:

Genarally the type of load is accepted as a main criteria for the classification of cracks and fractures. The three typical categories of cracks are (See Attachment; Page 2):

- a) cracks due to mechanical load,
- b) cracks due to thermal load and
- c) cracks due to corrosion.

In most cases these loads occur in combination.

Corrosion induced cracks and fractures furthermore fall into two categories depending on whether or not mechanical loading is involved. Cracks formed without any influence of mechanical loads usually show an intergranular corrosion. As indicated with the expression usually, intergranular corrosion cracks can sometimes occur though also under the influence of mechanical load.

The hydrogen-induced cracking and hydrogen induced stress corrosion cracking is not dealt with in this paper.

## 2.2 Prerequisites:

Stress corrosion cracking occurs in metals only under the simultaneous, combined effects of the following factors: a susceptible material, a specific environment, and a specific load. (See Attachment; Page 3):

The significant parameters of each of these conditions are in detail for the

Material:

- -Type
- -Average chemical composition
- -Metallurgical structure (microstructure distribution of precipitates, orientation of grains, dislocation interactions, amount of ferrite in cast stainless steel or austenitic-ferritic steel)
- -Thermal inputs (heat treatment, welding -> sensitisation (migration of chromium carbides to the grain boundaries in austenitic stainless steel))
- -Surface condition-Cold formed structure

Environment:

- -Composition / impurities
- -Temperature / threshold temperature
- -Concentration / leaching of other components
- -Pre-service conditions (e.g. contamination of surfaces)

Loading:

- -Operational tensile stress (concentration at notches, abrupt changes,
- wedges)
- -Residual stress (cold forming, welding)

However there is no complete explanation why some environmental conditions cause cracking in one alloy and not in others. Brass, for example, fails if subjected to stress in the presence of ammonia, but copper / gold alloys do not.

Page 4 of the attachment offers a small overview of Alloy systems and environment.

If the surface of the material shows uniform corrosion or shallow pit formations, no stress corrosion cracking will usually occur. Only deep pits i.e. pitting corrosion on the surface can produce cracking, if stresses are high enough.

As with most chemical reactions, stress corrosion cracking is accelerated by increasing temperature. Threshold temperatures have been identified from room temperature to high temperature.

In many cases it is difficult to measure the exact chemical composition of the surrounding electrolyte. Of course it is possible to measure the overall composition of moist gaseous or liquid flows. The composition under deposits, in sections with no flow or in condensed drops is not so easily determined. A further disturbance factor for the analysis is that normally the concentration in drops taken as samples is increased through evaporation of the water.

There are many different ways to bring corrosive agents into the fluid of a water-/ steam-cycle. One must consider very carefully pre-service contamination (e.g. residues on the surface caused by fabrication, testing ,shipment or storage on site) and possible leaching of substances from other components in the circuit (e.g. chlorides and sulphides from concrete, gasket or insulation material).

The effect of mechanical load falls in two categories: those built in during manufacturing, producing residual stresses, and the applied loading from the normal operation of the component.

During manufacturing residual stresses can be caused by cold forming procedures, assembling processes as well as welding. The aforementioned welding is the most dangerous one. As a consequence of the heating and cooling effect on the surface of a component following welding, extremely high residual tensile stresses can occur, which can approach the yield point of the material.

The necessary amount of stress to initiate stress corrosion cracking is depending to a great extent on the other two factors environment and material. No general rules can be defined.

Investigations show, that the stress locally (at the crack front) often is above the yield point whereas the main section shows normal stress loading.

If the stress load is increased, the time until cracking occurs decreases.

Stress corrosion cracking often occurs at locations where stress concentrations are present during service as a consequence of the design of the component. Any kind of notch, keyway, perforations, screw threads, abrupt changes in shaft diameters, and the like should be assessed critically because of their susceptibility to SCC.

Stress corrosion cracking has only been observed in connection with tensile stresses. Compression stresses do not produce any stress corrosion cracking.

### 2.3 Characteristics:

### 2.3.1 Macroscopic:

The crack propagates perpendicular to the axis of principal stress in the component with no signs of plastic deformation. Even in highly ductile materials no or little plastic deformation occurs. The developing sharp notch at the crack tip forms zones with very high stress concentrations.

Originating at surfaces, which usually only show slight corrosive attacks, the cracks can occur as a single crack or in greater not obers. The surfaces of opened up cracks are usually velvety smooth, but can appear roug when there is a greater incidence of intergranular constituents or more pronounced crack canching.

### 2.3.2 Microscopic:

Stress corrosion cracking can occur in various modes: totally transgranular, totally intergranular, or mixed. Intergranular tacking means the cracks follow the boundaries of the grains. Transgranular cracking means the cracks run straight through the grains with no preference to the grain boundaries. (See Attachment; Page 5):

Stress corrosion cracking is normally in ergranular in Aluminium Alloys, Low Carbon Steels, Annealed Monel, α-Brass, and sensitised stainless steel, (at least initially). Intergranular or transgranular are Magnesium Alloys, Copper Alloys and Nickel Alloys. Intergranular and transgranular are austenitic steel in hot caustic media. Transgranular in β-Brass and in austenitic steel in combination with chlorides.

Exceptions to each of these general rules of crack appearance are known.

Transgranular stress corrosion cracking occurs more frequently in face-centred cubic metals (fcc) such as austenitic steels. Body-centred cubic metals (bcc), e.g. ferritic steel, are less susceptible. As a consequence the industry has developed a type of steel with a mixed microstructure, the so-called DUPLEX-steels. They have a considerably higher resistance against transgranular stress corrosion cracking.

Cracks vary in degree of branching or subsidiary cracks. Most cracks display multi branched "river-delta" patterns. They can though also occur without any branches.

## 2.4 Theory of mechanism:

The detailed mechanism to explain every aspect of the phenomenon of stress corrosion cracking has not been established yet. Several research programs are currently under way. All discussed theories have been observed in laboratory tests with the result that presently all of them have some degree of scientific support.

The currently discussed theories can be classified into one of the following groups /6/:

### Electrochemical active path dissolution theory:

An electrochemical cell is formed on the surface between two areas of slightly differing potential. The more active area becomes the anode (susceptible to corrosion) and in presence of an electrolyte the dissolution of metal commences. Because of the formation of a protective layer or passive skin at the sidewalls the corrosion is directed to the tip of the crack. In this small area stress causes the rupture of the protective film and new active material is exposed to further corrosion. Thus a sharp crack tip propagates through the material whereas the sides are protected and do not show any signs of uniform corrosion attack. In case of intergranular cracking the substance of the boundary is the active part and the crack follows the boundary line. (See Attachment; Page 6):

### Stress absorption theory

Stress weakens bonds between atoms on the metal surface, forming dislocations. At these dislocations damaging ions are absorbed causing bonds to break and forming a crack in which adsorption continues.

### Corrosion tunnel theory:

Formations of rows of corrosion pits lengthen into an array of parallel corrosion tunnels. The uncorroded walls between the tunnels rupture mechanically to produce crack advancement.

Hydrogen embrittlement or hydrogen induced stress corrosion cracking theory:

This theory is usually considered as a phenomenon of its own. (see chapter 2.1 above). Atomic hydrogen deposits at a cathode for any of several reasons. However, some atomic hydrogen can diffuse into the metallic lattice to embrittle the metal and increase internal stresses to ultimately form cracks. This kind of cracking occurs exclusively in unalloyed and low-alloy steels as well as martensitic steels. The susceptibility to this type is greatest around room temperature.

### 2.5 Preventive measures:

The preventive measure to reduce the risk of stress corrosion cracking to occur is based on the three prerequisites material, environment and stresses and include among others: (See Attachment; Page 7):

- Stress relief annealing where possible,
- Residual compression of the surface layer through rolling or shot peening, if annealing is not possible,
- Clean environment during and after service through purging, inert gas (nitrogen)
- Avoid stress concentration (any form of notches: abrupt changes, keyways, screw threads)

- Cathodic protection, with regard to hydrogen embrittlement
- Coating layer

- Other material: nickel-alloys instead 304 stainless steel

stainless steel with Nb / Ti stabilising and low carbon content

carbon steel instead of stainless steel ferritic-austenitic steel DUPLEX

In addition every susceptible component should be monitored throughout its whole life and capable for further examinations in case of evidence.

## 3 Corrosion fatigue: (See Attachment; Page 8):

In case of corrosion fatigue the cycling load is accompanied by a corrosion mechanism. According to DIN 50 900 corrosion fatigue is defined as 'the formation of transgranular, low-ductility cracks in metals due to simultaneous effects of alternating mechanical loads and corrosion'. The distinction line between the classical fatigue and corrosion fatigue is not clearly marked. The fractures are classified depending on the magnitude of the cyclic load or the contribution of corrodents. Every environment, also in the surrounding moist air, contains some kind of corrodent. Therefore pure classical fatigue can only be observed under vacuum conditions. With high-frequent load-changes and large amplitudes the crack features looks like more the ones of classical fatigue, with low frequent amounts they looks more the ones of stress corrosion cracking.

In contrast to stress corrosion cracking for fatigue corrosion no specific conditions regarding the corrosion system (materials / corrodents) and the magnitude of the load is required.

With active corrosion of the material cracks originate at sites of stress concentration (e.g. notches, corrosion pits, abrupt steps in cross section). In passive materials corrosion fatigue cracks are mainly caused on smooth surfaces by stimulation of local metal dissolution (e.g. emerging slip bands or repeatedly destroyed protective layers).

Corrosion fatigue can occur in the active and passive condition of the material. The cracks propagate perpendicular to the principal stress. In case of active material the crack surface presents a scarred surface with numerous preinduced cracks. The surface in the passive condition is usually smooth.

The microscopic distinction of the typical features of pure fatigue from fatigue corrosion is difficult. Cracks of corrosion fatigue also run transgranularly. On the surface sometimes corrosion products are detectable. In case of predominate mechanical load fatigue lines or striations can be observed. In case of predominate corrosive load one can observe the crack features of stress corrosion cracking as fine structured and a share of intergranular cracks.

## 4 Strain induced corrosion cracking: (See Attachment; Page 9):

Strain-induced corrosion cracking is defined as a process between fatigue corrosion and stress corrosion cracking.

In DIN 50900 it is described as "Local corrosion with crack forming in metals as a consequence of a mechanical damage of protective coatings due to repeated critical stretching or shrinking of a component".

This means a protective layer build by the material, e.g. magnetite layer in pipes of steam boilers, is destroyed as a result of strain reversal due to mechanical stresses, and the free surface is exposed to a corrosive attack. The strain reversal can be a consequence of quickly changing operation condition, e.g. fluctuating steam pressure. It can also happen that the expansion of a component is hindered by the construction and the resulting compression stresses in the protective layers crack the coating. With every load cycle the mechanism is repeated at the crack tip, supported by the stress concentration due to the notch, and the crack propagates through the material.

Strain-induced corrosion cracking is limited to materials which build distinct protective coatings.

The macroscopic characteristics are usually a small number of individual cracks on the surface, perpendicular to the tensile stress. The surfaces of opened up cracks are generally smooth.

Regarded through a microscope, the cracks run transgranularly. Sometimes corrosion products can be detected.

- 5 Conclusions: (See Attachment; Pages 10 and 11):
- 6 Cases: (See Attachment: SCC Cases; Pages 1 3):

#### 7 Literature:

/1/ Rasterelektronenmikroskopische Untersuchungen von Metallschäden L. Engel/ H. Klingele Gerling Institut für Schadenforschung und Schadenverhütung, Köln, 1974

/2/ The Appearance of cracks and fractures in metallic materials Stahl und Eisen

/3/ Systematic Analysis of technical failures G. Lange Deutsche Gesellschaft für Metallkunde 1986

/4/ Korrosion der Metalle, Begriffe DIN 50 900, Teil 1 Deutsches Institut für Normung e.V., April 1982 /5/ Problems of stress corrosion cracking in engineering insurance H. B. Schittek IMIA 6-39(87)E

/6/ Stress corrosion cracking D. Anliker THE LOCOMOTIVE

/7/ Spannungsrißkorrosion - SpRK P. Forchhammer Lecture Paper 1996



# Stress corrosion cracking in engineering insurance


- Introduction
- · SCC

- Classification
- Characteristics
- Appearance
- Theorie of mechanism
- Preventive measures
- Corrosion Fatigue
- Strain induced SCC
- Conclusion

IMIA 1997
- Stress Corrosion Cracking -



# Classification of cracks and fractures



Pres. Sun City; 1997 • Gerling-Konzern, Druck: 07.11.1997; 09.35 page: 2



# Prerequisites of SCC

# Material

- Chemical composition
- Metallurgical structure
- Thermal inputs
- Surface condition
- Cold formed structures

# **Environment**

- Corrodent
- Temperature
- Concentration
- Pre-service condition

# SCC

# Mechanical loading

- Operational tensile stressResidual stress (forming, welding)

Pres. Sun City; 1997 © Gerling-Konzem, Druck: 07.11.1997, 09:35

page: 3



# Alloy systems and environments

A STATE OF THE PARTY OF THE PAR	4.3
<b>Alloy Syst</b>	OTTO
AHUY KIYAL	

Carbon Steels

Ferritic Stainless Steel
Austenitic Stainless Steel

Precipitation Hardening Stainless

Steel

Inconel

Nickel Alloys

Aluminium

Copper Alloys

Gold Alloys

Magnesium Alloys

Monel

Titanic Alloys

## Corrodent or Environment

Sodium Hydroxide, Nitrate Solutions, Cyanides, Mixed Acids, Seawater,

Acidic Hydrogen, Sulfide Solutions, Water, Ammonia, Amines

Marine Atmosphere

Chlorides in presence of oxygen, Sodium Hydroxide, Polythionic Acids,

Sulfides

Marine Atmosphere, Acidic Hydrogen Sulfide Solutions

Caustic Soda Solutions, Mercury

Sodium Hydroxide, Hydrofluoric Acid

Chloride solution, Seawater, Marine Atmosphere, Mercury, Hydrogen

Sulfide

Ammonia Vapors and Solutions, Amines, Mercury Compounds

Chlorides, Hypochlorite Solutions, Acetic Acid-Salt Solutions

Chloride Solutions, Rural and Coastal Atmospheres

Fused Caustic Soda, Hydrofluorid Acid, Mercury

Nitric Acid, Hot Chloride Solutions, Methanol, Ethanol



# Microscopic appearance

Intergranular

Low carbon steels

Annealed monel

α-Brass

Sensitized stainless steel (at least initially)


Intergranular or mickel alloys


Intergranular and transgranular

Transgranular

β-Brass


Austenite (chlorides)





Transgranular







# Preventive measures

- Avoid stress concentration by design
- Stress-relief annealing
- Residual compression in the surface layer: rolling or shot peening
- Environment clean during and after service: purging, inert gas (nitrogen)
- Cathodic protection
- Coating/layer
- Other material (e.g. carbon steel instead of stainless steel, DUPLEX)



# Corrosion fatigue

"The formation of transgranular, low-ductility cracks in metals due to simultaneous effects of altering mechanical loads and corrosion"

- DIN-specification 50 900 -



# Strain induced corrosion cracking

"Local corrosion with crack forming in metals as a consequence of a mechanical damage of protective coatings due to repeated critical stretching or shrinking of a component!"

- DIN-specification 50 900 -

# SCC - Cases

Date: 07.11.1997 GERLING

Country	Insured plant	Damaged part	Year of construction	Date of claims	Causes of claim	Type of SCC	Amount or claim in Mio US\$
Germany	Refuse incineration	Boiler- evaporator	1993	1993	Caustic for boil-out keeps to long time inside the tubes	Intergranular	1,1
	Refuse incineration	Boiler- evaporator	1994	1994	High concentration of caustic for boil-out and stagnation of circulation in a part of the evaporator and admission of caustic into the steam pipe work	Intergranular	7,4
	Refinary	Boiler- superheater	1995 (rebuilded)	1995	Boil-out of the superheater	Intergranular and transgranular	2,6
	Nuclear power	Pipework near the nuclear reactor made of austenitic steel	1983	1993	Welding mistakes and material	Intergranular and transgranular	3,4
	Nuclear power	Pipework near the nuclear reactor made of austenitic steel	1977	1995	Welding mistakes and material	Intergranular and transgranular	5,7 + 11,4 (rebuilding )
	Nuclear power	Pipework near the nuclear reactor made of austenitic steel	1974	1996	Marking tapes with chlorides in the adhesive	Transgranular	1,7
	Nuclear power	Austenitic steel of the shell in the core	1972	1994	Residual stress and material	Intergranular	17,2
	Nuclear power	Ceracks in bolts		1990	Chloride from bolt-lubricant during erection	Transgranular	3,0
	Nuclear power	Pipework near the nuclear reactor	1974	1993	Austenitic steel; welding mistakes and material	Intergranular	5,0
	Waste incineration	Activated coke filter		1992	Consequential damage at the housing due to SCC at the shut-off device of the fluegas duct; residual stresses due to cold-forming in sealing ledge		0,6
	Waste incineration	Steam boiler		1990	Residual stresses in the inner tube of soot-blowers	Transgranular	

# SCC - Cases

Date: 07.11.1997 GERLING

Country	Insured plant	Damaged part	Year of construct ion		Causes of claim	Type of SCC	Amount or claim in Mio US\$
Germany	Waste incineration	Steam boiler		1994	Attack of caustic alkaline in connecting tube of superheaters during erection	Intergranular	0,9
	Combined Cycle Power Plant	Waste heat boiler		1992	Residual stresses due to welding	Intergranular	0,4
Switzerland	Nuclear power	Shroud	1967	1990		Intergranular	4,8
	Nuclear power	Generator		1979			10,6 + 3,3 (conseq. damage)
		Building tie rod	1996	1996			1 (due to conseq. damage)
United Kingdom	Waste heat recovery	Boiler- superheater	1987	1994	Material	Transgranular	5,5 (incl. conseq. damage)
Canada	Paper mill	Black liquor, recovery boiler, superheater tubes	1988	1989			13,7
	Office building	Tensile cable for reinforcement of concrete	1981/ 1983	1992			14,6
USA	Chemical plant	Steamboiler-drum	1960	1991			2,1
	Power station (fossil fueled)	Water tube boiler, superheater tubes and steam turbine blades (SCC not clear)		1990	Condenser tubes ruptured resulting in salt and salt water to enter the boiler and the turbine		12,7 (in total) / 1,0 (superheater)
	Film manufacturing facility	Jacketed reactor, vessel	1966	1993	Insulation wool wrapped around the vessel contained leachable chloride	Transgranular	2,1

# SCC - Cases

Date: 07.11.1997 GERLING

Country	Insured plant	Damaged part	Year of construct ion	Date of claims	Causes of claim	Type of SCC	Amount or claim in Mio US\$
USA	Refinery	Absober column with propane in amine service		1984	Repair weld 10 years ago: 4 pre-rupture cracks in HEZ	Hydrogen induced cracking	152,4 physical damage +
	Power station	Steam turbine, disk failure (last stage)		1980	Poor material		75,0
		Ammonia storage tank		1973	Ammonia service		1,5
Japan	Power station	Gas turbine	1994	1994	Fuel gas with corrosive ingredients		2,4
	Chemical plant	Steam turbine	1991	1989	Na-salt in the steam		1,0
	Chemical plant	Steam turbine	1991	1989	Na-salt in the steam		1,0